

**PRESTO  
CARPET STAIN REMOVER**

This product is a uniquely formulated product with a blend of effective dry and wet cleaning compounds and degreasers that quickly remove spots and stains caused by: grease, oil, dirt, mud, salt, ketchup, coffee, alcoholic beverages, soft drinks, chocolate, urine, blood\* and vomit\*. Penetrates and cleans without leaving residue. Brightens as it restores nap and texture.

\*Wear gloves

Always test carpet in a small, inconspicuous area for color-fastness and damage to fiber backing as carpeting quality varies widely. Do not use on white or light colored carpet. Do not use with any other stain or odor removing chemicals.

**DIRECTIONS:** Can sprays upside down only. Remove protective cap. Shake well. Hold can upside down. Point opening in spray tip towards spot or stain. Depress the tab on the top of the spray tip to spray. Hold can at arm's length. It is not necessary to bend down to apply this product. Apply in short bursts until spot or stain is covered. Allow a short period of time for spotter to penetrate stain. Blot spot with a clean cloth working from center of stain out. Stain or spot will be gone in seconds. Excessive deposits of grease, oil or ink may require additional applications. Wait until material is dry before reapplying.

**MODO DE EMPLEO:** El bote se usa hacia abajo únicamente. Remueva la tapa protectora, agítese bien. Póngalo hacia abajo. Apunte el aplicador hacia la mancha. Presione el aplicador. Mantenga el bote a la altura de la mano. No es necesario agacharse. Aplique poco a poco hasta que la mancha este cubierta. Permita un corto tiempo para que el producto actúe. Limpie con un trapo del centro hacia afuera. La mancha se removerá en segundos. Depósitos de grasa, aceite o tinta pueden necesitar más de una aplicación. Permita que la alfombra se seque antes de volver a aplicar. No se use en alfombras blancas o de colores ligeros.

**WARNING:** Flammable aerosol. Contains gas under pressure; may explode if heated. Causes eye irritation. Keep away from heat, sparks, open flames, and hot surfaces. -No smoking. Pressurized container: Do not pierce or burn, even after use. Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F. Store in a well-ventilated place. Wash hands thoroughly after handling. If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical attention.

**ADVERTENCIA:** Aerosol inflamable. Contiene gas a presión; puede explotar si se calienta. Causa irritación de los ojos. Mantenga lejos de calor, chispas, llamas abiertas, y superficies calientes. -No fumar. Envase presurizado: No perforo ni queme, incluso después de usar. Proteja de la luz solar. No exponga a temperaturas que excedan 50°C/122°F. Almacene en un lugar bien-ventilada. Lávese bien las manos después de manipular. Si cae en los ojos: Enjuague cuidadosamente con agua durante varios minutos. Remueva lentes de contacto, si están presentes y fáciles de remover. Continúe enjuagando. Si persiste la irritación ocular: Consulte con un medico.

**CONTAINS (CAS#):** Water (7732-18-5), 2-Butoxyethanol (111-76-2), Propane/n-Butane (68476-86-8), Isopropyl Alcohol (67-63-0), Diethylene Glycol Monobutyl Ether (111-34-5).

Made in USA

**ITEM 2480**

# PRESTO

## Carpet Spot & Stain Remover

Removedor de Manchas de Alfombras

**Cleans Spots and Stains  
Safe on Most Fabrics  
Destroys Odors**

**WARNING / ADVERTENCIA:  
FLAMMABLE AEROSOL.  
CONTAINS GAS UNDER PRESSURE;  
MAY EXPLODE IF HEATED.  
AEROSOL INFLAMABLE.  
CONTIENE GAS A PRESIÓN;  
PUEDE EXPLOTAR SI SE CALIENTA.**

**NET WT. 18 OZ. (510 g)**

**QuestSpecialty**  
Corporation

P.O. Box 624 • Brenham, TX 77834  
713.896.8188



HEALTH	1
FLAMMABILITY	1
REACTIVITY	1
PERSONAL	A